PLAY22322

AUDIO

2-pair unbalanced audio cable: PC2230.

- Connectors: CAJ348MV jack st (m) 6,3 mm –> 2x CAJ248MV jack mn (m) 6,3 mm.






PC2230



CAJ348MV CAJ248MV



Code	BK	m
PLAY22322L03		3
PLAY22322L05		5
PLAY22322L10		10

PLAY22323

AUDIO

2-pair unbalanced audio cable: PC2230.

- Connectors: 2x CAJ248MV jack mn (m) 6,3 mm –> 2x CAJ248MV jack mn (m) 6,3 mm.






PC2230



CAJ248MV CAJ248MV



Code	BK	m
PLAY22323L03		3
PLAY22323L05		5
PLAY22323L10		10

PLAY23324

AUDIO

2-pair balanced audio cable: PC2330.

- Connectors: 2x CAJ348MV jack st (m) 6,3 mm –> 2x CAJ348MV jack st (m) 6,3 mm.






PC2330



CAJ348MV CAJ348MV



Code	BK	m
PLAY23324L03		3
PLAY23324L05		5
PLAY23324L10		10

PLAY22325

AUDIO

2-pair unbalanced audio cable: PC2230.

- Connectors: 2x CAJ238MV jack mn (m) 6,3 mm –> 2x CAR284MV RCA (m).






PC2330



CAJ238MV CAR284MV



Code	BK	m
PLAY22325L03		3
PLAY22325L05		5
PLAY22325L10		10

PLAY22326


AUDIO

2-pair unbalanced audio cable: PC2230.
• Connectors: 2x CAR284MV RCA (m) –> 2x CAR284MV RCA (m).









Code	BK	m
PLAY22326L03		3
PLAY22326L05		5
PLAY22326L10		10

PLAY22327


AUDIO

2-pair unbalanced audio cable: PC2235.
• Connectors: 2x RCA (m) –> 2x RCA (m).





Code	BK	m
PLAY22327L01		1
PLAY22327L03		3
PLAY22327L05		5
PLAY22327L10		10



PLAY22328


AUDIO

2-pair unbalanced audio cable: PC2235.
• Connectors: jack st (m) 3,5 mm –> 2x RCA (m).





Code	BK	m
PLAY22328L01		1
PLAY22328L03		3
PLAY22328L05		5
PLAY22328L10		10




PLAY53313

DMX

DMX cable: HP5330.
• Connectors: CAX304MV XLR (m) 3p –> CAX304FV XLR (f) 3p.







Code	BK	m
PLAY53313L01		1
PLAY53313L03		3
PLAY53313L05		5
PLAY53313L010		10
PLAY53313L015		15
PLAY53313L020		20


PLAY53315

DMX

DMX cable: HP5330.
• Connectors: CAX504MV XLR (m) 5p –> CAX504FV XLR (f) 5p.







Code	BK	m
PLAY53315L01		1
PLAY53315L03		3
PLAY53315L05		5
PLAY53315L010		10
PLAY53315L015		15
PLAY53315L020		20