

TOUR66460

NEUTRIK POWER/AUDIO

Power/signal cable: HC6640.
- Neutrik audio connectors: CANC3FXX XLR-f 3p and CANC3MXX XLR-m 3p.
- Power: MESV10 IEC plug and MEPV10 3p IEC socket.


HC6640


CANC3FXX


CANC3MXX


MESV10


MEPV10

Code	BK	m
TOUR66460L05		5
TOUR66460L10		10
TOUR66460L15		15
TOUR66460L20		20
TOUR66460L25		25
TOUR66460L30		30



TOUR66470

NEUTRIK POWER/AUDIO

Power/signal cable: HC6640.
- Neutrik audio connectors: CANC3FXX XLR-f 3p and CANC3MXX XLR-m 3p.
- Power: 911133 Shuko 16A plug and MENAC3FCA Neutrik POWERCON socket.


HC6640


CANC3FXX


CANC3MXX


911133


MENAC3FCA

Code	BK	m
TOUR66470L05		5
TOUR66470L10		10
TOUR66470L15		15
TOUR66470L20		20
TOUR66470L25		25
TOUR66470L30		30



TOUR66480

NEUTRIK POWER/AUDIO

Power/signal cable: HC6640.
- Neutrik audio connectors: CANC3FXX XLR-f 3p and CANC3MXX XLR-m 3p.
- Power: 911113 3p 16A plug and MENAC3FCA Neutrik POWERCON socket.


HC6640


CANC3FXX


CANC3MXX


911133


MENAC3FCA

Code	BK	m
TOUR66480L05		5
TOUR66480L10		10
TOUR66480L15		15
TOUR66480L20		20
TOUR66480L25		25
TOUR66480L30		30



TOUR66490

Power/signal cable: HC6640.
- Neutrik audio connectors: CANC3FXX XLR-f 3p and CANC3MXX XLR-m 3p.
- Power: MENAC3FCB Neutrik powerCON plug and MENAC3FCA Neutrik powerCON socket.


HC6640


CANC3FXX


CANC3MXX


MENAC3FCB


MENAC3FCA

Code	BK	m
TOUR66490L05		5
TOUR66490L10		10
TOUR66490L15		15
TOUR66490L20		20
TOUR66490L25		25
TOUR66490L30		30



TOUR76613

NEUTRIK POWER/DMX

Power/DMX signal cable: HC7660.

- Neutrik audio connectors: CANC3MXX XLR-m 3p and CANC3FXX XLR-f 3p
- Power: 911113 3p 16A plug and MENAC3FXW Neutrik powerCON socket.


HC7660


CANC3FXX


CANC3MXX


911113


MENAC3FXW

Code	m	DMX
TOUR76613L01BK	1	3-p
TOUR76613L02BK	2	3-p
TOUR76613L03BK	3	3-p
TOUR76613L05BK	5	3-p
TOUR76613L10BK	10	3-p
TOUR76613L15BK	15	3-p
TOUR76613L20BK	20	3-p
TOUR76613L25BK	25	3-p
TOUR76613L30BK	30	3-p



TOUR76615

NEUTRIK POWER/DMX

Power/DMX signal cable: HC7640.

- Neutrik audio connectors: CANC3MXX XLR-m 5p and CANC3FXX XLR-f 5p
- Power: 911113 3p 16A plug and MENAC3MWX Neutrik powerCON socket.


HC7660


CANC5MXX


CANC5FXX


911113


MENAC3MXW

Code	m	DMX
TOUR76615L01BK	1	5-p
TOUR76615L02BK	2	5-p
TOUR76615L03BK	3	5-p
TOUR76615L05BK	5	5-p
TOUR76615L10BK	10	5-p
TOUR76615L15BK	15	5-p
TOUR76615L20BK	20	5-p
TOUR76615L25BK	25	5-p
TOUR76615L30BK	30	5-p



TOUR76623

NEUTRIK POWER/DMX

Power/DMX signal cable: HC7640.

- Neutrik audio connectors: CANC3MXX XLR-m 3p and CANC3FXX XLR-f 3p
- Power: MENAC3FXW Neutrik powerCON plug and MENAC3MXW Neutrik powerCON socket.


HC7660


CANC3FXX


CANC3MXX


MENAC3FXW


MENAC3MXW

Code	m	DMX
TOUR76623L01BK	2	3-p
TOUR76623L02BK	3	3-p
TOUR76623L03BK	4	3-p
TOUR76623L05BK	5	3-p
TOUR76623L10BK	10	3-p
TOUR76623L15BK	15	3-p
TOUR76623L20BK	20	3-p
TOUR76623L25BK	25	3-p
TOUR76623L30BK	30	3-p



TOUR76625

NEUTRIK POWER/DMX

Power/DMX signal cable: HC7640.

- Neutrik audio connectors: CANC5MXX XLR-m 5p and CANC5FXX XLR-f 5p
- Power: MENAC3FXW Neutrik powerCON plug and MENAC3MXW Neutrik powerCON socket.


HC7660


CANC5MXX


CANC5FXX


MENAC3MXW


MENAC3FXW

Code	m	DMX
TOUR76625L01BK	1	5-p
TOUR76625L02BK	2	5-p
TOUR76625L03BK	3	5-p
TOUR76625L05BK	5	5-p
TOUR76625L10BK	10	5-p
TOUR76625L15BK	15	5-p
TOUR76625L20BK	20	5-p
TOUR76625L25BK	25	5-p
TOUR76625L30BK	30	5-p