


AD151


Metal adapter
- 3 poles XLR plug -> 3 poles XLR plug.





AD159


Metal adapter
- 3 poles XLR socket -> 6,3 mm stereo jack plug.





AD155


Metal adapter
- 3 poles XLR plug -> 5 poles XLR socket





AD152


Metal adapter
- 3 poles XLR socket -> 3 poles XLR socket.





AD160


Metal adapter
- 3 poles XLR plug -> 6,3 mm stereo jack plug.





AD156


Metal adapter
- 3 poles XLR socket -> 5 poles XLR plug.





AD153


Metal adapter
- 3 poles XLR socket -> 6,3 mm mono jack socket.





AD161


Metal adapter
- 3 poles XLR socket -> RCA plug.





AD30


Metal adapter for acoustic speakers
- 4p Speakon plug-> 3p XLR plug





AD154


Metal adapter
- 3 poles XLR plug -> 6,3 mm mono jack socket.





AD162


Metal adapter
- 3 poles XLR plug -> RCA plug





AD40


Metal adapter for acoustic speakers
- 4p Speakon plug-> 3p XLR socket





AD157


Metal adapter
- 3 poles XLR socket -> 6,3 mm mono jack plug.





AD163


Metal adapter
- 3 poles XLR socket -> RCA socket.





AD10


Metal adapter for acoustic speakers
- 4p Speakon socket -> 3p XLR plug.





AD158

Metal adapter
- 3 poles XLR plug -> 6,3 mm mono jack plug.





AD164


Metal adapter
- 3 poles XLR plug -> RCA socket.





AD20

Metal adapter for acoustic speakers
- 4p Speakon socket -> 3p XLR socket





CANL8MM

Neutrik 8 poles SPEAKON plug-to-plug adapter, made of plastic.



CANL4MMX

Neutrik 4 poles SPEAKON plug-to-plug adapter, made of plastic.



AD174

Plastic adapter
- 4p Speakon plug -> 4p Speakon plug.



AD166

Metal adapter with push-lock
- 6,3 mm stereo jack socket -> 6,3 mm stereo jack socket



AD280

Plastic adapter
- 6,3 mm mono jack socket -> 6,3 mm mono jack socket.




AD065

Plastic adapter
- RCA socket -> 6,3 mm mono jack plug




AD120

Plastic adapter
- 6,3 mm stereo jack socket -> 3,5 mm stereo jack plug





AD318

Plastic adapter
- 3,5 mm stereo jack socket -> 6,3 mm stereo jack plug




AD329

Plastic adapter
- 6,3 mm mono jack socket -> RCA socket





AD323

Plastic adapter
- 2 x 6,3 mm mono jack socket -> 6,3 mm mono jack plug.



AD324

Plastic adapter
- 2 x 6,3 mm stereo jack socket -> 6,3 mm stereo jack plug




AD325

Plastic adapter
- 2 x RCA socket -> RCA plug



AD322

Plastic adapter
- 2 x RCA socket -> 6,3 mm stereo jack plug



AD328

Plastic adapter
- RCA socket -> RCA socket



AD327

Plastic adapter
- 2 x RCA socket -> 2 x RCA socket.



AD800

Plastic adapter
- SCART plug -> 3 RCA sockets for video and L & R audio (selectable) input/output plus S-VHS socket.



AD751

Metal adapter
- BNC plug -> RCA plug.



AD752

Metal adapter
- BNC socket -> RCA plug.



AD753

Metal adapter
- BNC plug -> BNC plug.



AD754

Metal adapter
- RCA socket. -> BNC plug.



AD755

Metal adapter
- BNC socket -> BNC socket.